

RCT Labor code	Vehicle Line	Description of repair	Labor HRS
RCT0J101	E-Series Underbody Gen3	Fuel Tank	1.5
RCT0J101A	E-Series Underbody Gen3	De-Pressurizing Fuel System (All platforms)	0.5
RCT0J102	E-Series Underbody Gen3	Service access flange (remove and replace) R&R	0.5
RCT0J103	E-Series Underbody Gen3	Service access flange (remove and install) R&I	0.5
RCT0J104	E-Series Underbody Gen3	Mechanical 80% OPD fill valve	0.5
RCT0J105	E-Series Underbody Gen3	Pressure relief outlet valve	0.5
RCT0J106	E-Series Underbody Gen3	Shield, fuel tank heat, rear tank body	0.2
RCT0J107	E-Series Underbody Gen3	Shield, fuel tank heat, front tank body	0.2
RCT0J108	E-Series Underbody Gen3	Shield, fuel tank heat, Tank Hdr Cap	0.2
RCT0J110	E-Series Underbody Gen3	Bracket and crush sleeve (All)	0.2
RCT0J116	E-Series Underbody Gen3	In Tank Filters (2)	0.3
RCT0J117	E-Series Underbody Gen3	In Tank Filter Brackets	0.5
RCT0J118	E-Series Underbody Gen3	Sending Unit, Fuel Level	0.5
RCT0J119	E-Series Underbody Gen3	Sending Unit twin site(electronic portion only)	0.3
RCT0J120	E-Series Underbody Gen3	FUEL PUMP ASSEMBLY	0.5
RCT0J121	E-Series Underbody Gen3	Supply valve assembly	0.5
RCT0J122	E-Series Underbody Gen3	Pump, Jet	0.3
RCT0J123	E-Series Underbody Gen3	Fuel line "Y" filter to supply assembly	0.2
RCT0J124	E-Series Underbody Gen3	Fuel return circuit assembly	0.3
RCT0J125	E-Series Underbody Gen3	Jiffy-tite fitting 3/8" supply	0.3
RCT0J126	E-Series Underbody Gen3	Jiffy-tite fitting 1/4" return	0.3
RCT0J127	E-Series Underbody Gen3	Bleeder valve on tank	0.3
RCT0J129	E-Series Underbody Gen3	Bracket, Cross Member Mounting	0.3
RCT0J131	E-Series Underbody Gen3	Bracket, Rear E350 Frame Mounting	0.5
RCT0J132	E-Series Underbody Gen3	Bracket, Front E350 Frame Mounting	0.5
RCT0J135	E-Series Underbody Gen3	Bracket, Fuel Filter	0.5
RCT0J137	E-Series Underbody Gen3	Bracket, Rear Fuel Line Support	0.2
RCT0J138	E-Series Underbody Gen3	Bracket, Trans Dipstick Support	0.3
RCT0J140	E-Series Underbody Gen3	Bracket, FRPCM to Intake	0.4
RCT0J201	E-Series Underbody Gen3	Fuel Rail Assembly	0.7
RCT0J202	E-Series Underbody Gen3	Fuel IPTS - 10K OHM Thermistor	0.3
RCT0J203	E-Series Underbody Gen3	Service Injector- R&R (1) after rail removal	0.3
RCT0J203A	E-Series Underbody Gen3	Service Injector- R&R (2) after rail removal	0.6
RCT0J203B	E-Series Underbody Gen3	Service Injector- R&R (3) after rail removal	0.9
RCT0J203C	E-Series Underbody Gen3	Service Injector- R&R (4) after rail removal	1.2
RCT0J203D	E-Series Underbody Gen3	Service Injector- R&R (5) after rail removal	1.5
RCT0J203E	E-Series Underbody Gen3	Service Injector- R&R (6) after rail removal	1.8
RCT0J203F	E-Series Underbody Gen3	Service Injector- R&R (7) after rail removal	2.1
RCT0J203G	E-Series Underbody Gen3	Service Injector- R&R (8) after rail removal	2.4
RCT0J204	E-Series Underbody Gen3	(1) Fuel injector spacer tube after fuel rail removal	0.2
RCT0J204A	E-Series Underbody Gen3	(2) Fuel injector spacer tube after fuel rail removal	0.4
RCT0J204B	E-Series Underbody Gen3	(3) Fuel injector spacer tube after fuel rail removal	0.6
RCT0J204C	E-Series Underbody Gen3	(4) Fuel injector spacer tube after fuel rail removal	0.8
RCT0J204D	E-Series Underbody Gen3	(5) Fuel injector spacer tube after fuel rail removal	1.0
RCT0J204E	E-Series Underbody Gen3	(6) Fuel injector spacer tube after fuel rail removal	1.2
RCT0J204F	E-Series Underbody Gen3	(7) Fuel injector spacer tube after fuel rail removal	1.4
RCT0J204G	E-Series Underbody Gen3	(8) Fuel injector spacer tube after fuel rail removal	1.6
RCT0J205	E-Series Underbody Gen3	FLIM (Fuel Level Indicator Module)	0.3
RCT0J206A	E-Series Underbody Gen3	RFRPCM Bleed PORT	0.2
RCT0J206	E-Series Underbody Gen3	FRPCM	0.4
RCT0J206A	E-Series Underbody Gen3	FRPCM Bleed Port	0.2
RCT0J207	E-Series Underbody Gen3	SRM (Smart Relay Module)	0.4
RCT0J208	E-Series Underbody Gen3	FRPCM Purge Hose Assembly	0.2
RCT0J209	E-Series Underbody Gen3	Vapor Tube Assembly	0.3
RCT0J210	E-Series Underbody Gen3	FTP Sensor-Hose Assembly	0.3
RCT0J301	E-Series Underbody Gen3	Wire Harness, Complete Vehicle harness	2.0
RCT0J301A	E-Series Underbody Gen3	Wire Harness, Engine Compartment	1.0
RCT0J301B	E-Series Underbody Gen3	Wire Harness, Frame- Engine to Tank/Jumper	0.4

RCT0J301C	E-Series Underbody Gen3	Wire Harness, Tank	0.4
RCT0J301D	E-Series Underbody Gen3	Wire Harness, Tank Jumper	0.4
RCT0J301E	E-Series Underbody Gen3	Wire Harness, CAN Harness	0.5
RCT0J302	E-Series Underbody Gen3	Fuse Box Bracket	0.2
RCT0J303	E-Series Underbody Gen3	Jumper Harness-Fuel Injector(per injector)	0.1
RCT0J401	E-Series Underbody Gen3	3/8" Remote Fill Line, Nozzle to Filter	0.3
RCT0J402	E-Series Underbody Gen3	3/8" Remote Fill-Line - Filter to Tank	0.3
RCT0J403	E-Series Underbody Gen3	Bracket, Fuel Filler Neck Mounting	0.3
RCT0J404	E-Series Underbody Gen3	Fuel filler neck valve (remote fill valve)	0.5
RCT0J405	E-Series Underbody Gen3	Fuel Filter Bracket	0.2
RCT0J406	E-Series Underbody Gen3	Fuel Filter Assembly	0.5
RCT0J601	E-Series Underbody Gen3	Diamond Propane-Reflective (Tailgate)	0.1
RCT0J602	E-Series Underbody Gen3	Label-Propane Fuel Only	0.1
RCT0J603	E-Series Underbody Gen3	Label - Overflow Protection Device (Fuel Door)	0.1
RCT0J604	E-Series Underbody Gen3	Label-Bleeder Valve Inspection	0.1
RCT0J606	E-Series Underbody Gen3	Label, 350 PSIG Design Pressure (MV Supply Solenoid)	0.1
RCT0J609	E-Series Underbody Gen3	Label, Tank Valve Information	0.1
RCT0J610	E-Series Underbody Gen3	Label, Rear View Mirror Hang Tag	0.1
RCT0J620	E-Series Underbody Gen3	Decal,Warning PCM Programming	0.1
RCT0K101	E-Series In-Vehicle Gen3	Fuel Tank	2.5
RCT0K101A	E-Series In-Vehicle Gen3	De-Pressurizing Fuel System (All platforms)	0.5
RCT0K102	E-Series In-Vehicle Gen3	Service access flange (remove and replace) R&R	0.5
RCT0K103	E-Series In-Vehicle Gen3	Service access flange (remove and install) R&I	0.5
RCT0K104	E-Series In-Vehicle Gen3	Mechanical 80% OPD fill valve	0.5
RCT0K105	E-Series In-Vehicle Gen3	Pressure relief outlet valve	0.5
RCT0K109	E-Series In-Vehicle Gen3	Pressure relief 1" ID hose	0.5
RCT0K110	E-Series In-Vehicle Gen3	Bracket and crush sleeve (All)	0.2
RCT0K116	E-Series In-Vehicle Gen3	In Tank Filters (2)	0.3
RCT0K117	E-Series In-Vehicle Gen3	In Tank Filter Brackets	0.5
RCT0K118	E-Series In-Vehicle Gen3	Sending Unit, Fuel Level	0.5
RCT0K119	E-Series In-Vehicle Gen3	Sending Unit twin site(electronic portion only)	0.3
RCT0K120	E-Series In-Vehicle Gen3	FUEL PUMP ASSEMBLY	0.5
RCT0K121	E-Series In-Vehicle Gen3	Supply valve assembly	0.5
RCT0K123	E-Series In-Vehicle Gen3	Fuel line "Y" filter to supply assembly	0.2
RCT0K124	E-Series In-Vehicle Gen3	Fuel return circuit assembly	0.3
RCT0K125	E-Series In-Vehicle Gen3	Jiffy-tite fitting 3/8" supply	0.3
RCT0K126	E-Series In-Vehicle Gen3	Jiffy-tite fitting 1/4" return	0.3
RCT0K127	E-Series In-Vehicle Gen3	Bleeder valve on tank	0.3
RCT0K128	E-Series In-Vehicle Gen3	Remote bleeder valve	0.3
RCT0K129	E-Series In-Vehicle Gen3	Bracket, Cross Member Mounting	0.3
RCT0K131	E-Series In-Vehicle Gen3	Bracket, Rear E350 Frame Mounting	0.5
RCT0K132	E-Series In-Vehicle Gen3	Bracket, Front E350 Frame Mounting	0.5
RCT0K135	E-Series In-Vehicle Gen3	Bracket, Fuel Filter	0.5
RCT0K137	E-Series In-Vehicle Gen3	Bracket, Rear Fuel Line Support	0.2
RCT0K138	E-Series In-Vehicle Gen3	Bracket, Trans Dipstick Support	0.3
RCT0K140	E-Series In-Vehicle Gen3	Bracket, FRPCM to Intake	0.4
RCT0K201	E-Series In-Vehicle Gen3	Fuel Rail Assembly	0.7
RCT0K202	E-Series In-Vehicle Gen3	Fuel IPTS - 10K OHM Thermistor	0.3
RCT0K203	E-Series In-Vehicle Gen3	Service Injector- R&R (1) after rail removal	0.3
RCT0K203A	E-Series In-Vehicle Gen3	Service Injector- R&R (2) after rail removal	0.6
RCT0K203B	E-Series In-Vehicle Gen3	Service Injector- R&R (3) after rail removal	0.9
RCT0K203C	E-Series In-Vehicle Gen3	Service Injector- R&R (4) after rail removal	1.2
RCT0K203D	E-Series In-Vehicle Gen3	Service Injector- R&R (5) after rail removal	1.5
RCT0K203E	E-Series In-Vehicle Gen3	Service Injector- R&R (6) after rail removal	1.8
RCT0K203F	E-Series In-Vehicle Gen3	Service Injector- R&R (7) after rail removal	2.1
RCT0K203G	E-Series In-Vehicle Gen3	Service Injector- R&R (8) after rail removal	2.4
RCT0K204	E-Series In-Vehicle Gen3	(1) Fuel injector spacer tube after fuel rail removal	0.2
RCT0K204A	E-Series In-Vehicle Gen3	(2) Fuel injector spacer tube after fuel rail removal	0.4
RCT0K204B	E-Series In-Vehicle Gen3	(3) Fuel injector spacer tube after fuel rail removal	0.6

RCT0K204C	E-Series In-Vehicle Gen3	(4) Fuel injector spacer tube after fuel rail removal	0.8
RCT0K204D	E-Series In-Vehicle Gen3	(5) Fuel injector spacer tube after fuel rail removal	1.0
RCT0K204E	E-Series In-Vehicle Gen3	(6) Fuel injector spacer tube after fuel rail removal	1.2
RCT0K204F	E-Series In-Vehicle Gen3	(7) Fuel injector spacer tube after fuel rail removal	1.4
RCT0K204G	E-Series In-Vehicle Gen3	(8) Fuel injector spacer tube after fuel rail removal	1.6
RCT0K205	E-Series In-Vehicle Gen3	FLIM (Fuel Level Indicator Module)	0.3
RCT0K206	E-Series In-Vehicle Gen3	FRPCM	0.4
RCT0K206A	E-Series In-Vehicle Gen3	FRPCM Bleed PORT	0.2
RCT0K207	E-Series In-Vehicle Gen3	SRM (Smart Relay Module)	0.4
RCT0K208	E-Series In-Vehicle Gen3	FRPCM Purge Hose Assembly	0.2
RCT0K209	E-Series In-Vehicle Gen3	Vapor Tube Assembly	0.3
RCT0K210	E-Series In-Vehicle Gen3	FTP Sensor-Hose Assembly	0.3
RCT0K301	E-Series In-Vehicle Gen3	Wire Harness, Complete Vehicle harness	2.0
RCT0K301A	E-Series In-Vehicle Gen3	Wire Harness, Engine Compartment	1.0
RCT0K301B	E-Series In-Vehicle Gen3	Wire Harness, Frame- Engine to Tank/Jumper	0.4
RCT0K301C	E-Series In-Vehicle Gen3	Wire Harness, Tank	0.4
RCT0K301D	E-Series In-Vehicle Gen3	Wire Harness, Tank Jumper	0.4
RCT0K301E	E-Series In-Vehicle Gen3	Wire Harness, CAN Harness	0.5
RCT0K302	E-Series In-Vehicle Gen3	Fuse Box Bracket	0.2
RCT0K303	E-Series In-Vehicle Gen3	Jumper Harness-Fuel Injector(per injector)	0.1
RCT0K401	E-Series In-Vehicle Gen3	3/8" Remote Fill Line, Nozzle to Filter	0.3
RCT0K402	E-Series In-Vehicle Gen3	3/8" Remote Fill-Line - Filter to Tank	0.3
RCT0K403	E-Series In-Vehicle Gen3	Bracket, Fuel Filler Neck Mounting	0.3
RCT0K404	E-Series In-Vehicle Gen3	Fuel filler neck valve (remote fill valve)	0.5
RCT0K405	E-Series In-Vehicle Gen3	Fuel Filter Bracket	0.2
RCT0K406	E-Series In-Vehicle Gen3	Fuel Filter Assembly	0.5
RCT0K601	E-Series In-Vehicle Gen3	Diamond Propane-Reflective (Tailgate)	0.1
RCT0K602	E-Series In-Vehicle Gen3	Label-Propane Fuel Only	0.1
RCT0K603	E-Series In-Vehicle Gen3	Label - Overflow Protection Device (Fuel Door)	0.1
RCT0K604	E-Series In-Vehicle Gen3	Label-Bleeder Valve Inspection	0.1
RCT0K606	E-Series In-Vehicle Gen3	Label, 350 PSIG Design Pressure (MV Supply Solenoid)	0.1
RCT0K609	E-Series In-Vehicle Gen3	Label, Tank Valve Information	0.1
RCT0K610	E-Series In-Vehicle Gen3	Label, Rear View Mirror Hang Tag	0.1
RCT0K620	E-Series In-Vehicle Gen3	Decal,Warning PCM Programming	0.1
RCT0L101	E-Series-Aft Axle Gen3	Fuel Tank	1.2
RCT0L101A	E-Series-Aft Axle Gen3	De-Pressurizing Fuel System (All platforms)	0.5
RCT0L102	E-Series-Aft Axle Gen3	Service access flange (remove and replace) R&R	0.5
RCT0L103	E-Series-Aft Axle Gen3	Service access flange (remove and install) R&I	0.5
RCT0L104	E-Series-Aft Axle Gen3	Mechanical 80% OPD fill valve	0.5
RCT0L105	E-Series-Aft Axle Gen3	Pressure relief outlet valve	0.5
RCT0L106	E-Series-Aft Axle Gen3	Shield, fuel tank heat, rear tank body	0.2
RCT0L107	E-Series-Aft Axle Gen3	Shield, fuel tank heat, front tank body	0.2
RCT0L108	E-Series-Aft Axle Gen3	Shield, fuel tank heat, Tank Hdr Cap	0.2
RCT0L109	E-Series-Aft Axle Gen3	Pressure relief 1" ID hose(New York System)	1.0
RCT0L116	E-Series-Aft Axle Gen3	In Tank Filters (2)	0.3
RCT0L117	E-Series-Aft Axle Gen3	In Tank Filter Brackets	0.5
RCT0L118	E-Series-Aft Axle Gen3	Sending Unit, Fuel Level	0.5
RCT0L119	E-Series-Aft Axle Gen3	Sending Unit twin site(electronic portion only)	0.3
RCT0L120	E-Series-Aft Axle Gen3	FUEL PUMP ASSEMBLY	0.5
RCT0L121	E-Series-Aft Axle Gen3	Supply valve assembly	0.7
RCT0L123	E-Series-Aft Axle Gen3	Fuel line "Y" filter to supply assembly	0.2
RCT0L124	E-Series-Aft Axle Gen3	Fuel return circuit assembly	0.3
RCT0L125	E-Series-Aft Axle Gen3	Jiffy-tite fitting 3/8" supply	0.3
RCT0L126	E-Series-Aft Axle Gen3	Jiffy-tite fitting 1/4" return	0.3
RCT0L127	E-Series-Aft Axle Gen3	Bleeder valve on tank	0.3
RCT0L133	E-Series-Aft Axle Gen3	Bracket, RH Aft Axle Fuel Tank Mounting	1.0
RCT0L134	E-Series-Aft Axle Gen3	Bracket, LH Aft Axle Fuel Tank Mounting	1.0
RCT0L135	E-Series-Aft Axle Gen3	Bracket, Fuel Filter	0.5
RCT0L136	E-Series-Aft Axle Gen3	Bracket, VMV Valve Mounting	0.5

RCT0L137	E-Series-Aft Axle Gen3	Bracket, Rear Fuel Line Support	0.2
RCT0L138	E-Series-Aft Axle Gen3	Bracket, Trans Dipstick Support	0.3
RCT0L140	E-Series-Aft Axle Gen3	Bracket, FRPCM to Intake	0.4
RCT0L201	E-Series-Aft Axle Gen3	Fuel Rail Assembly	0.7
RCT0L202	E-Series-Aft Axle Gen3	Fuel IPTS - 10K OHM Thermistor	0.3
RCT0L203	E-Series-Aft Axle Gen3	Service Injector- R&R (1) after rail removal	0.3
RCT0L203A	E-Series-Aft Axle Gen3	Service Injector- R&R (2) after rail removal	0.6
RCT0L203B	E-Series-Aft Axle Gen3	Service Injector- R&R (3) after rail removal	0.9
RCT0L203C	E-Series-Aft Axle Gen3	Service Injector- R&R (4) after rail removal	1.2
RCT0L203D	E-Series-Aft Axle Gen3	Service Injector- R&R (5) after rail removal	1.5
RCT0L203E	E-Series-Aft Axle Gen3	Service Injector- R&R (6) after rail removal	1.8
RCT0L203F	E-Series-Aft Axle Gen3	Service Injector- R&R (7) after rail removal	2.1
RCT0L203G	E-Series-Aft Axle Gen3	Service Injector- R&R (8) after rail removal	2.4
RCT0L203H	E-Series-Aft Axle Gen3	Service Injector- R&R (9) after rail removal	2.7
RCT0L203I	E-Series-Aft Axle Gen3	Service Injector- R&R (10) after rail removal	3
RCT0L204	E-Series-Aft Axle Gen3	(1) Fuel injector spacer tube after fuel rail removal	0.2
RCT0L204A	E-Series-Aft Axle Gen3	(2) Fuel injector spacer tube after fuel rail removal	0.4
RCT0L204B	E-Series-Aft Axle Gen3	(3) Fuel injector spacer tube after fuel rail removal	0.6
RCT0L204C	E-Series-Aft Axle Gen3	(4) Fuel injector spacer tube after fuel rail removal	0.8
RCT0L204D	E-Series-Aft Axle Gen3	(5) Fuel injector spacer tube after fuel rail removal	1.0
RCT0L204E	E-Series-Aft Axle Gen3	(6) Fuel injector spacer tube after fuel rail removal	1.2
RCT0L204F	E-Series-Aft Axle Gen3	(7) Fuel injector spacer tube after fuel rail removal	1.4
RCT0L204G	E-Series-Aft Axle Gen3	(8) Fuel injector spacer tube after fuel rail removal	1.6
RCT0L204H	E-Series-Aft Axle Gen3	(9) Fuel injector spacer tube after fuel rail removal	1.8
RCT0L204I	E-Series-Aft Axle Gen3	(10) Fuel injector spacer tube after fuel rail removal	2.0
RCT0L205	E-Series-Aft Axle Gen3	FLIM (Fuel Level Indicator Module)	0.3
RCT0L206A	E-Series-Aft Axle Gen3	FRPCM Bleed PORT	0.2
RCT0L206	E-Series-Aft Axle Gen3	FRPCM	0.4
RCT0L207	E-Series-Aft Axle Gen3	SRM (Smart Relay Module)	0.4
RCT0L208	E-Series-Aft Axle Gen3	FRPCM Purge Hose Assembly	0.2
RCT0L209	E-Series-Aft Axle Gen3	Vapor Tube Assembly	0.3
RCT0L210	E-Series-Aft Axle Gen3	FTP Sensor-Hose Assembly	0.3
RCT0L301	E-Series-Aft Axle Gen3	Wire Harness, Complete Vehicle harness	2.0
RCT0L301A	E-Series-Aft Axle Gen3	Wire Harness, Engine Compartment	1.0
RCT0L301B	E-Series-Aft Axle Gen3	Wire Harness, Frame- Engine to Tank/Jumper	0.4
RCT0L301C	E-Series-Aft Axle Gen3	Wire Harness, Tank	0.4
RCT0L301D	E-Series-Aft Axle Gen3	Wire Harness, Tank Jumper	0.4
RCT0L301E	E-Series-Aft Axle Gen3	Wire Harness, CAN Harness	0.5
RCT0L302	E-Series-Aft Axle Gen3	Fuse Box Bracket	0.2
RCT0L303	E-Series-Aft Axle Gen3	Jumper Harness-Fuel Injector(per injector)	0.1
RCT0L401	E-Series-Aft Axle Gen3	3/8" Remote Fill Line, Nozzle to Filter	0.3
RCT0L402	E-Series-Aft Axle Gen3	3/8" Remote Fill-Line - Filter to Tank	0.3
RCT0L403	E-Series-Aft Axle Gen3	Bracket, Fuel Filler Neck Mounting	0.3
RCT0L404	E-Series-Aft Axle Gen3	Fuel filler neck valve (remote fill valve)	0.5
RCT0L405	E-Series-Aft Axle Gen3	Fuel Filter Bracket	1.4
RCT0L406	E-Series-Aft Axle Gen3	Fuel Filter Assembly	0.5
RCT0L601	E-Series-Aft Axle Gen3	Diamond Propane-Reflective (Tailgate)	0.1
RCT0L602	E-Series-Aft Axle Gen3	Label-Propane Fuel Only	0.1
RCT0L603	E-Series-Aft Axle Gen3	Label - Overflow Protection Device (Fuel Door)	0.1
RCT0L604	E-Series-Aft Axle Gen3	Label-Bleeder Valve Inspection	0.1
RCT0L606	E-Series-Aft Axle Gen3	Label, 350 PSIG Design Pressure (MV Supply Solenoid)	0.1
RCT0L609	E-Series-Aft Axle Gen3	Label, Tank Valve Information	0.1
RCT0L610	E-Series-Aft Axle Gen3	Label, Rear View Mirror Hang Tag	0.1
RCT0L620	E-Series-Aft Axle Gen3	Decal,Warning PCM Programming	0.1